

Autowatch Car Alarm False Trigger Codes

If the Autowatch 457RLi car alarm goes off, a record of what caused this trigger can be determined from the 'Trigger Report Back' feature.

This is accessed by entering the program code '1,2,3' followed by the code '1,1', instructions on how to do this can be read from [Car Security Systems - Programming New Remotes For Autowatch Car Alarms](#). From our 'Your Guide' Section.

Autowatch 457RLi Car Alarm False Trigger Codes	
1 Flash	Movement Sensor (Ultrasonic or WPIR)
2 Flashes	WPIR Zone (When allocated to its own zone)
3 Flashes	Panic
4 Flashes	Ignition
5 Flashes	Negative Door
6 Flashes	Positive Door / Hotwire
7 Flashes	Boot
8 Flashes	Bonnet

Trigger information is automatically cleared once alarm has been turned on and off ten times without triggering.

Page last updated December 2012

© DragonCarAudio.co.uk - Permission given for forums and forum posts to link to this page.